

SCATTERMOON Instructions

Instructions for operation:

Plug the power cord in and go.

Turn the sensitivity knob all the way to the left for stationary activation. Slowly move the knob clockwise for desired mic sensitivity.